



















ASSEMBLY INSTRUCTION

91-0376 CHAIR

PARTS LIST							
PARTS#		Pattern	Q' ty	PARTS#	Description	Pattern	Q' ty
A	Bolt Dia $\varnothing 1/4 \times 2"$		12PCS	K	Lock Washer $\varnothing 1/4 \times 12\text{mm}$		12PCS
B	Bolt Dia $\varnothing 5/16 \times 2"$		4PCS	L	Chair Back		1PC
C	Flat Washer $\varnothing 5/16 \times 19\text{mm}$		4PCS	M	Left side frame		1PC
D	Lock Washer $\varnothing 5/16 \times 12\text{mm}$		4PCS	N	Right side frame		1PC
E	Wood Screw (#8 $\times 5/8"$)		8PCS	O	Front rail		1PC
F	Allen Wrench 4mm		1PC	P	Bottom rail		1PC
G	Wood Plug $\varnothing 20\text{mm}$		2PCS	Q	Rocker runner		2PCS
H	Wood Plug $\varnothing 14\text{mm}$		10PCS	R	Seat cushion		1PC
I	L bracket		4PCS	S	Allen Wrench 5mm		1PC
J	Flat Washer $\varnothing 1/4 \times 16\text{mm}$		2PCS				

STEP 4.

Level the chair and place chair upright on level surface and tighten all bolts securely. Then put the seat cushion (R) on the chair, assemble seat cushion (R) to chair back rail and front rail using Wood Screw, L bracket (E+I), tighten it. Last, cover the wooden plug (G+H) in the hole.

