

WYNN/COSMO MIRROR

Assembly instructions:

PART LISTS

NO.	DESCRIPTION	IMAGE	Q'TY
P1	MIRROR		1PC
P2	WALL HANGER BAR		1PC

HARDWARE LISTS

NO.	DESCRIPTION	IMAGE	Q'TY
H1	SCREW M4 X 35mm	()amma-	4PCS
H2	PHILIP SCREW		NOT PROVIDE

NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy assembly should be performed by two people.

Estimate assenbly time:2 minutes



