


Please read below before assembly

- Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.
- Failure to follow these instructions may cause the bolts to misalign during assembly.

DISCLAIMERS:

- WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.
- BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.




TOOLS REQUIRED (NOT INCLUDED)



PARTS LIST

1	HEADBOARD PANEL		1 PC
2	RIGHT HEADBOARD POST		1 PC
3	LEFT HEADBOARD POST	(EE)): :) :::}	1 PC
4	RIGHT FOOTBOARD POST	₩:.: `	1 PC
(5)	LEFT FOOTBOARD POST		1 PC
6	HEADBOARD STRETCHER	1	1 PC
7	SIDE RAIL	8 8	2 PCS
8	FOOTBOARD		1 PC
9	CANOPY LONG RAIL		2 PCS
10	CANOPY SHORT RAIL		2 PCS
11	MIDDLE SUPPORT		1 PC
12	SUPPORT LEG	€	5 PCS
13	SLAT ROLL		2 SETS


PARTS LIST



HARDWARE LIST

Α	BOLT - Ø5/16" x 1-3/4"		6 PCS
В	BOLT - Ø5/16" x 2-3/4"		6 PCS
С	BOLT - Ø1/4" x 1/2"		8 PCS
D	BOLT - Ø1/4" x 1-1/4"		4 PCS
Е	STUD BOLT - Ø5/16" x 3-1/2"		8 PCS
F	LARGE LOCK WASHER - Ø5/16" x 1/2"		12 PCS
G	LARGE FLAT WASHER - Ø5/16" x 5/8"	0	12 PCS
Н	SMALL LOCK WASHER - Ø1/4" x 1/2"		4 PCS
I	SMALL FLAT WASHER - Ø1/4" x 5/8"	0	4 PCS
J	WOODEN PLUG - Ø3/4" x 3/8"		6 PCS
K	CRESCENT WASHER - Ø5/16"		8 PCS
L	HEXAGON NUT - Ø5/16"	()	8 PCS
М	WOOD SCREW - Ø1/8" x 1-1/8"	© 11111111111	8 PCS
N	ALLEN KEY		1 PC
0	WRENCH	€ G	1 PC


STEP 1 LOCATE HARDWARE PER BELOW DRAWING



CARTON B - PART INSIDE : 2,3,4,5,7,9,10,11


В	3 PCS
F	3 PCS
G	3 PCS
N	1 PC


NOTE: PLEASE FLIP THE FRONT FACE UP





Α		1 PC
С		1 PC
F		1 PC
G	0	1 PC
N		1 PC


NOTE: BACK OF HEADBOARD
















STEP 9





STEP 10




K	Ø	8 PCS
L		8 PCS
0	S	1 PC


NOTE: DO NOT FULLY TIGHTEN BOLTS


























Care & Maintenance

Do...



Wipe up spills immediately.



Dust and pick-up spills using a clean, non-colored, lint-free, dry cloth.



Use mild non-abrasive soap and water.

Don't...



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture in direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.