MADISON PARK®

ASSEMBLY INSTRUCTIONS

Description: Kirtley Writing Desk

Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY	
P1	Table Top		1	
P2	Short Frame Leg		1	
P3	Long Frame Leg		1	
P4	Short Stretcher	•	1	
P5	Long Stretcher		1	

Hardware List


Item	Description		QTY
H1	Bolts Ø5/16"*1-1/2"	0	10
H2	Lock Washer Ø5/16"	0	10
H3	Flat Washer Ø5/16"*3/4"	9	10
H4	Allen Wrench 4mm		1
H5	Plastic Cap	~	4

DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:


Step 1. Assemble the Desk on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach Short Stretcher (P4) & Long Stretcher (P5) to the Short Frame Leg (P2) & Long Frame Leg (P3) as shown below.



Step 2. Turn over the Table Top (P1) on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the Base to the Table Top (P1) as shown below.



Step 3: Turn the Desk over and place it upright on a level surface. Insert the Plastic Cap (H5) to cover the Bolt holes as shown below. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY:
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase