



# ASSEMBLY INSTRUCTIONS

Description: FIONA DINING CHAIR




**Important safety instructions:**

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







**Pre-assembly:**

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

| Item | Description |   | QTY |
|------|-------------|---|-----|
| P1   | Chair Back  |    | 1   |
| P2   | Seat Frame  |    | 1   |
| P3   | Front Legs  |  | 2   |

Hardware List

| Item | Description         |   | QTY |
|------|---------------------|---|-----|
| H1   | Bolts 1/4" x 1-1/2" |  | 2   |
| H2   | Bolts 1/4" x 2-3/8" |  | 4   |
| H3   | Bolts 1/4 x 3"      |  | 4   |
| H4   | Lock Washers 1/4"   |  | 10  |
| H5   | Flat Washers 1/4"   |  | 10  |
| H6   | Allen Key           |  | 1   |

**DISCLAIMER:**


**WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.**

**Assembly Procedures:**





\*Assemble the Chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.


Step 1: Attach the Seat Frame (P2) to the Chair Back (P1) as shown below.

- (H1)x2 Bolts 1/4" x 1-1/2"
- (H3)x4 Bolts 1/4" x 3"
- (H4)x6 Lock Washers 1/4"
- (H5)x6 Flat Washers 1/4"
- (H6)x1 Allen Key




Step 2: Attach the Front Legs (P3) to the Seat Frame (P2) as shown below.

- (H2)x4 Bolts 1/4" x 2-3/8" 
- (H4)x4 Lock Washers 1/4" 
- (H5)x4 Flat Washers 1/4" 
- (H6)x1 Allen Key 



Step 3: Turn the assembled chair to an upright position. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY:  
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.  
THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY,  
AND ENSURE STABILITY.

Thank you for your purchase