


ASSEMBLY INSTRUCTIONS

LANCASTER FAUX LEATHER WOOD FRAME

UPHOLSTERED DINING CHAIR

INK+IVY




Please read below before assembly

- Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.
- Failure to follow these instructions may cause the bolts to misalign during assembly.

DISCLAIMERS:

- WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.
- BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.



PEOPLE NEEDED









WEIGHT LIMIT









ESTIMATED TIME

PARTS LIST


①	RIGHT LEG FRAME		1 PC
②	LEFT LEG FRAME		1 PC
③	X STRETCHER		1 PC
④	SEAT CUSHION		1 PC
⑤	BACK CUSHION		1 PC







HARDWARE LIST


A	HEXAGON BOLT- Ø5/16" x 1"		4 PCS
B	BOLT- Ø5/16" x 1-5/8"		8 PCS
C	LOCK WASHER Ø5/16"		12 PCS
D	FLAT WASHER Ø5/16"		12 PCS
E	ALLEN KEY-5/16"		1 PC
F	WRENCH		1 PC

STEP 1 LOCATE PARTS AND HARDWARE PER BELOW DRAWING








STEP 2

B		2 PCS
C		2 PCS
D		2 PCS
E		1 PC








STEP 3

B		6 PCS
C		6 PCS
D		6 PCS
E		1 PC




STEP 4

A		4 PCS
C		4 PCS
D		4 PCS
F		1 PC



STEP 5



Care & Maintenance

Do...



Wipe up spills immediately.



Dust and pick-up spills using a clean, non-colored, lint-free, dry cloth.



Use mild non-abrasive soap and water.


Don't...



Do not put hot items directly on furniture surface.




Do not clean furniture with harsh cleansers or polish.



Do not place furniture in direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.